


# THREAD TURNING TOOLHOLDERS

## FourCut External



Insert mm	Part Number	B/H mm	L mm	F mm
12	SER1010H12	10	100	10
12	SER1212H12	12	100	12
12	SER1616H12	16	100	16
12	SER2020K12	20	125	20
12	SER2525M12	25	150	25

### with Internal Coolant

Insert mm	Part Number	B/H mm	L mm	F mm
12	SER1212H12-J	12	100	12
12	SER1616H12-J	16	100	16
12	SER2020K12-J	20	125	20
12	SER2525M12-J	25	150	25

### Spare Parts

Insert mm	Screw to insert	Torx key
12	T9XM3	TORX_T9

■ The Part Numbers are for Right Hand Toolholders. For Left Hand specify L instead of R. The Price is 10% higher for L.

